

NICHIBAN SELF ADHESIVE CELLULOSE TAPE

CELLULOSE TAPE NO.405 (Industrial use)

CELLULOSE TAPE is a trusted brand of adhesive tapes popular in Japan for almost 70 years and known for its flexibility and the soft feel in use. CELLULOSE TAPE is a natural-material film made from trees (wood pulp), a recyclable plant resource.

This base material is different from that of transparent tapes made from petroleum.



Applications

Sealing envelopes

Craft projects

Packaging

Affixing temporary notes, etc

Sticking up posters



- ☑ **Natural gum** - Adhesive composed mostly of natural gum
- ☑ **Natural resin** - Natural resin is added to make it adhesive
- ☑ **Wood chip** - Raw materials for cellophane
- ☑ **Wood pulp** - The plant fiber "wood pulp" is extracted from the wood chip.
- ☑ **Viscose** - The orange-brown liquid "viscose" is obtained by chemical treatment of wood pulp which is a main ingredient of cellophane.
- The viscose is used as the basis of manufacturing cellophane film.



Cellophane made from wood pulp

Core made from recycled paper

Adhesive made from natural gum/resin

Mainly all plant materials



Made from natural materials

Natural materials are the main component of the cellophane, the adhesive and the core so they will return to the soil.



Eco-friendly with low CO₂ emissions when incinerated

Our cellulose tape emits less CO₂ than OPP tape.



Strong adhesive sticks well to anything

With strong adhesive for firm sticking, it adheres well to all types of surfaces.



Low level of static electricity reduces attraction to paper

Easy to use for a variety of tasks since static electricity is minimized, making the paper less likely to be attracted to the tape when it is being affixed.



Easily cut with tape dispenser

It is easy to use since it can be easily cut with the tape dispenser.



Easily cut by hand

The best tape are used in offices, schools and everywhere since it can be cut easily by hand.

CELLULOSE TAPE for clean room



There is no risk of paper powder because of plastic core.

Color CELLULOSE TAPE



It's easy to discern with Color CELLULOSE TAPE.

Printed CELLULOSE TAPE



Made-to-Order printed CELLULOSE TAPE.



Ready-Made printed CELLULOSE TAPE.

CELLULOSE TAPE Easy-Open

It's easy to peel off because of no adhesion at both ends.



for fixing a sachet of liquid seasoning.



for fixing a food pack, a film of cake...

Product number	Product name	Base material	Pressure sensitive adhesive	Thickness (mm)	Peel strength (N/10mm)	Tensile strength (N/10mm)	Elongation (%)
405	CELLULOSE TAPE	Cellophane	Rubber adhesive	0.050	3.93	41.6	23
CRCT-18	CELLULOSE TAPE for clean room			0.050	3.93	41.6	23
430	Color CELLULOSE TAPE			0.051	3.62	41.4	23
450	CELLULOSE TAPE (Custom ordered design)			0.052	3.00	38.0	27
450	CELLULOSE TAPE (Limited design)			0.052	3.00	38.0	27
CTEZ-FR	CELLULOSE TAPE Easy-Open for food pack (red)			0.055	3.98	41.5	26
CTEZ-FG	CELLULOSE TAPE Easy-Open for food pack (green)			0.055	3.98	41.5	26
CTEZ-FW	CELLULOSE TAPE Easy-Open for food pack (white)						
CTEZ-CK	CELLULOSE TAPE Easy-Open for fixing a film of cake						
CTEZ-KS	CELLULOSE TAPE Easy-Open for food pack of tea-ceremony dishes						
CTEZ-SG	CELLULOSE TAPE Easy-Open for food pack of fresh fish						
CTEZ-CF	CELLULOSE TAPE Easy-Open for food pack of cut fruit						
CTEZ-RA	CELLULOSE TAPE Easy-Open for fixing a sachet of liquid seasoning						